

### OVERVIEW

- When spraying helium over the test part, use the lowest practical flow of helium. For determining if a leak exists, a larger flow may be appropriate. However, for pinpointing leak location, reduce the helium flow to around 1-3 bubbles per second when submersing the probe tip in liquid.
- To assist in pinpointing a leak location, spray the suspect leak location in short spurts. Note the response time of the leak detector as well as the magnitude of the signal that appears. A short response time and a large signal indicate a location close to the spray point.
- When leak testing a part with multiple potential leak locations, start by spraying locations at the top of the part and work down to the bottom of the part. Helium will rise and can give a misleading location of the leak.
- Compressed air can be used on the part to dissipate the helium trapped on or near the part. This may help reduce the helium signal to the leak detector to make leak location quicker.

### PROCEDURE

1. Connect spray probe to regulated helium using 10 Ft. tubing and fitting provided. Make sure the helium source is pre-regulated down to 30 psig or lower. All fitting connections should be leak tight.
2. For LHSP04 models, adjust regulator to achieve a light flow of helium (1-2 psig). For LHSP01 models, no regulator is supplied with the spray probe, so a customer supplied regulator should be used to adjust to the correct helium spray pressure.
3. For gross leak testing, the helium spray pressure can be higher (1-3 psig). Helium set to a higher pressure will achieve a higher flow.
4. For pin-pointing leak locations, use a very small helium pressure. By spraying with the spray probe tip placed in a small cup of water, the amount of helium gas being released from the tip can be seen and gauged.



LHSP01



LHSP04

### USE OF PROBE TIPS

The spray probe is supplied with rigid and flexible tips. The rigid tip is used for general spraying and the flexible tip is for leak testing hard-to-reach areas.

- The flexible tip can be bent, but do not over-bend the tip. Make sure the probe tip does not get plugged.
- To change the tips, remove the nut from the end of the probe and replace with a different tip. Tighten nut slightly past hand-tight.
- To avoid damage to the plastic sleeve of the flexible tip, do not over bend near the swaged connection.

### CAUTION

Follow precautions to ensure safe operation.



- Do not inhale helium gas. Helium is non-toxic, but may cause suffocation. Lack of sufficient oxygen can cause serious injury or death. Refer to Material Safety Data Sheet.
- Always use regulated helium. Do not exceed 60 psig when operating the spray probe. Never connect the spray probe directly to a helium bottle—even with spray probe model LHSP04 that includes a regulator.



Contact  
LACO Technologies  
for assistance.