

**LACO** TECHNOLOGIES  
USER MANUAL

---



---

ATL21G4 ROTARY VANE VACUUM PUMP

# CONTACT US

---



## PHONE/FAX

Toll Free: 800.465.1004  
Phone: 801.486.1004  
Fax: 801.486.1007

## ADDRESS

LACO Technologies, Inc.  
3085 West Directors Row  
Salt Lake City, UT 84104

## WEB

[www.lacotech.com](http://www.lacotech.com)  
[info@lacotech.com](mailto:info@lacotech.com)

## TECHNICAL SUPPORT & SERVICE

[techsupport@lacotech.com](mailto:techsupport@lacotech.com)

# CONTENTS

---

1. SCOPE .....	1
2. SAFETY .....	1
3. SPECIFICATIONS.....	2
4. INSTALLATION .....	5
5. BASIC OPERATION .....	7
6. MAINTENANCE .....	8
7. TROUBLESHOOTING .....	11
8. SPARE PARTS.....	12

## 1. SCOPE

---

This manual contains installation, operation, maintenance, and troubleshooting information for the ATL21G4 Rotary Vane Vacuum Pump. Please read the manual in its entirety before operating the pump.

LACO rotary vane vacuum pumps are designed to ensure safety when used properly. It is the responsibility of the user to follow safety-related warnings, cautions, notes, and other requirements described in this manual.

Returned equipment will not be accepted by LACO Technologies without prior authorization. Prior to shipping please call for a returned material authorization (RMA) number.

LACO Technologies reserves the right to cancel the warranty if the pump is disassembled without authorization, if pump fluids are used that are not compatible with the design and materials used in the manufacture of the pump, and if unauthorized spare parts are used. The manufacturer has the right to modify the product without notice.

## 2. SAFETY

---

Death or serious injury can result from improper use or application of this pump. If the pump will be exposed to toxic, explosive, pyrophoric, highly corrosive, or other hazardous process gases including greater than atmospheric concentrations of oxygen, contact LACO Technologies for specific recommendations.

**WARNING** This device is designed for only use in the field of coarse or fine vacuum. It can be used to suck off air or dry gases, which are not poisonous, aggressive or explosive .

**WARNING** Read the instruction manual before operating this device.

**WARNING** Do not modify or repair the rotating parts of this device.



### 2.1 SAFETY REQUIREMENT :

---

**CAUTION** Transportation, installation, maintenance and troubleshooting must be executed by a responsible, qualified personnel.

**CAUTION** This device must be set up according to this instruction manual.

- CAUTION** Ground the motor properly during installation. Disconnect the power before beginning installation, maintenance or repair work or before interchanging the input leads when correcting the direction of rotation. Disconnecting the power also avoids an unexpected start-up for pumps with automatically resetting thermal overloads.
- CAUTION** Please check the direction of rotation before power is turned on
- CAUTION** If the device couldn't accelerate up to its rated speed from the power switch turned on, please turn off the power immediately and check it carefully.
- CAUTION** The power supply must be turned off before moving, maintaining or repairing this device.
- CAUTION** Liquid and solid particles must not enter the pump. If device will be come in contact with moist air device must be equipped with gas ballast valve.
- CAUTION** The end cover is used to prevent contact and direct the cooling air flow, can not be removed; otherwise the motor will get overheating.

## 3. SPECIFICATIONS

### 3.1 ATL21G4 BASIC PARTS




## 3.2 ATL21G4 SPECIFICATIONS

*Table 1: ATL21G4 Specifications*


COMPONENT	DESCRIPTION
Pumping Speed @ 60 Hz	14 cfm, 24 m3/hr
Ultimate Pressure	2 Torr, 29.8 inHG
Standard Motor, CE Marked	120/240 Single Phase
Current	13.07 amps
Oil Capacity	0.53 quart
Weight Net	25.3 kg, 55.78 lbs.
Noise Level	72 dB(A)
Inlet Port	1/2" NPT
Ambient Operating Temperature	70° to 40° C (45° to 104° F)

### 3.2.1 ATL21G4 DIMENSIONS

(Measurements in mm)



### 3.2.2 ATL21G4 EXPLODED DRAWING



## 4. INSTALLATION

---

### 4.1 RECEIVING

---

Each rotary vane vacuum pump is inspected and carefully packed prior to shipment. Inspect it after carefully unpacking it. In case of external damage, retain the shipping container and notify the shipping agency and LACO Technologies immediately. The packing materials are designed specifically for the pump and should always be used when transporting the pump.

Unpack the pump and check for shipping damage as follows:

1. Inspect the outside of the shipping container for shipping damage.
2. Unpack the pump.
3. Thoroughly inspect the pump for damage.
4. If you find any damage, proceed as follows:
  - a. Save the shipping container, packing material, and parts for inspection.
  - b. Notify the carrier that made the delivery within 7 days of delivery.
  - c. File a claim with the carrier.
  - d. Contact LACO Technologies to make arrangements for replacing the damaged part(s).

### 4.2 REPORTING SHIPPING SHORTAGE

---

If you did not receive all the goods that you ordered, do the following:

1. Check the number of items listed on the packing slip. If the number of pieces listed is greater than the number of shipping containers received, contact the carrier concerning the missing piece(s).
2. Check the packing list to see if the missing item is on back order.
3. Carefully check the packing material and container to ensure that the missing item was not overlooked.
4. If you cannot find the item, please notify LACO Technologies immediately

### 4.3 REPORTING INCORRECT SHIPMENT

---

If the item received is not the item ordered, contact LACO Technologies immediately.



## 4.4 INITIAL FILLING WITH VACUUM PUMP FLUID

All LACO rotary vane vacuum pumps are shipped with a full change of vacuum pump fluid. Always be sure that the oil level is approximately in the middle of the low and high level marks in the oil level window and please note that upon start up of the pump, the oil level in the oil level window will drop slightly.

## 4.5 CONNECTING THE PUMP TO THE SYSTEM

### 4.5.1 PREPARATION

1. Select a well ventilated area, free of dust.
2. The pump should be placed conveniently to monitor the oil level of the pump.
3. We recommend the pump is operated in temperature over 50 °F.

### 4.5.2 ELECTRICAL CONNECTIONS

The pump should be mounted to a secure object so as not to be moved by the vibration of the pump. The pump should be installed and maintained horizontally at all times.

1. The supplied power voltage and frequency must be as the rating stated on the nameplate
2. The drive motor must be protected against overload by a fuse or circuit breaker matching the rating current on the nameplate



**CAUTION** Do not connect power to your pump until the blank off plate is removed from the exhaust port. Operating the pump with the exhaust port blanked off will damage the pump and can injure the operator.

All connections must be vacuum tight for your pump to achieve its ultimate pressure.

### CONNECTING TO SYSTEM

1. It is recommended to mount the pump to a secure object so as not to be moved by vibration. The pump should be installed and maintained horizontally at all times.
2. Install pump to system including intake and exhaust lines.



**CAUTION** Remove the exhaust port cover before starting the pump.

**WARNING** Ensure that your vacuum line is connected to the pump's intake port and not to the exhaust port. If your vacuum line has a closed valve, accidentally connecting it to the pump's exhaust port causes a dangerous overpressure.

**NOTE** Ideally, the inside diameter of the vacuum line should be the same size or larger than the (ID) of the intake port. If the vacuum line is too narrow, it will reduce the pumping speed.

3. It is not required to install an exhaust line because the pump includes an internal oil mist eliminator.

**WARNING** If installing an exhaust line do not install an exhaust line with a smaller ID than the exhaust port. Restrictions reduce the pumping speed and could damage the oil seals or cause dangerous overpressure in the pump.

## 5. BASIC OPERATION



### 5.1 SETUP

Before starting the pump, please complete the following checklist:

**CAUTION** Do not connect power to your pump until the blank off plate is removed from the exhaust port. Operating the pump with the exhaust port blanked off will damage the pump and can injure the operator.

1. Be sure that the pump is filled with the appropriate amount of vacuum fluid.
2. Be sure that all electrical connections have been properly wired and that there are no bare wires that could cause an electrical shock or fire.
3. Be sure that all system connections have been secured with the appropriate seal rings and clamps.

### 5.2 OPERATION

1. First click ON/OFF which is located on the 120V power cord supplied with the pump.
2. These vacuum pumps are not designed for use in corrosive service. When pumping hazardous or corrosive passes, we recommend the use of an inlet vacuum trap.
3. Periodically check the vacuum fluid level in the sight glass to be sure it is between the low and high levels.

4. If the vacuum fluid within the pump becomes discolored or contaminated, change the fluid as soon as possible. Operating the pump with contaminated or dirty oil will greatly reduce the life expectancy of the pump and may lead to the cancellation of the warranty.

### 5.3 ANTISUCKBACK

---

If the pump stops with the inlet under vacuum the antisuckback system will stop oil leakage into the vacuum chamber. It is recommended to not store the pump for extended periods of time with the inlet port under vacuum.

## 6. MAINTENANCE

---

### 6.1 INSPECTION

---

- Check vacuum oil frequently. You need to check whether the oil is brownish, dirty, or contains moisture.
- Always check oil level before you start up the pump.
- If oil level is lowered you can add oil to proper level.
- If the oil has been contaminated by any dust or water, you need to change the oil entirely.

To change the pump oil:

1. Allow the pump to cool for about 5 minutes.
2. Drain the contaminated oil completely through the drain plug (reference Section 3.1 "ATL21G4 BASIC PARTS" for oil drain plug location).
3. Close the drain plug.
4. Fill the new vacuum oil through the oil filling plug and check the oil level.

**NOTE** The pump oil temperature should be typically less than 65°C when operating.

### 6.2 PERIODIC SERVICE ITEMS

---

#### 6.2.1 VACUUM OIL

Below are guidelines for the rate of oil changes specific to various applications. There is no exact formula for the rate of oil change. Please note the specifics of your system and change the oil at a rate best for your specific application.

APPLICATION	CHANGE OIL WITHIN (HOURS)
High Vacuum in Lab environment, or system seldom exposed to the air	2,500
High Vacuum in manufacturing environment, often exposed to the air	1,200
Vacuum furnace, large gas-exhaust diffusion system, system with booster pump.	600
Vacuum drier, vacuum molding, vacuum packing	200
Vacuum distillation, low vacuum tank	120

## 6.2.2 PUMP FLUID

Every vacuum pump is designed to work best with a specific pump fluid and the fluid is an active part of the pumping mechanism. For best performance from your pump, care must be used to select fluid with the physical and chemical properties engineered from your pump. For LACO pumps the ideal fluid for general purposes pumping is LVO19. This is a moderately priced fluid that is engineered to give best vacuum and longest life in our pumps. Other fluids may give performance that is good enough for your needs but specifications are based on regular use of LVO19.

## 6.2.3 CHECKING THE PUMP FLUID

**WARNING** If the pump has been used on corrosive, toxic or volatile chemicals, observe proper safety precautions before removing the drain plug.



**CAUTION** Hydrocarbon pump fluid should be changed at the following times:

1. After a 100 hour break-in period of pump operation.
2. When the pump fluid becomes contaminated or is discolored.
3. When condensation in the pump fluid is present.
4. Before and after the pump has been stored for a long period of time.
5. Perfluoropolyether fluid should be reconditioned when it becomes contaminated.

**NOTE** Always change the pump fluid while the pump is warm to prevent condensables, such as water, from remaining in the pump.

Turn the pump off and change the fluid as follows:

1. Drain the fluid from the pump. Use your fingers to remove the oil fill cap and the oil drain plug from the pump; allow the fluid to drain into a suitable container. If the fluid fill cap or fluid drain cap cannot be

loosened with your fingers, cover them with a cloth and use pliers.

2. After the oil flow diminishes, switch ON the pump, allow it to run for about 10 seconds and then switch if OFF.
3. If the fluid drained from the pump is discolored, contains particulate, has a foul odor or is very dirty, flush out the pump using the procedure below until the drained fluid is clean. If your pump requires more than 2 flushes, a foreline trap or oil filtration unit should be installed on the pump.
  - a. Reinstall the fluid-drain plug with flat gasket into the fluid-drain port.
  - b. Refill the pump with vacuum pump fluid until the fluid level is visible in the lower rim of the fluid sight glass.
  - c. Blank off/on valve off the inlet port.
  - d. Turn ON the pump and allow it to run for about 10 minutes.
  - e. Turn the pump OFF and refer to step 1 to drain the vacuum fluid.
4. Charge the pump with fluid as follows:
  - a. Reinstall the fluid-drain plug with flat gasket into the fluid port.
  - b. Remove the fluid-fill cap and fill the pump to capacity with vacuum pump fluid.
  - c. Reinstall the fluid-fill cap with flat gasket.

### **6.3 LONG TERM STORAGE (2 WEEKS OR LONGER)**

---

Before placing a pump in long term storage, follow the procedure below:

1. Drain all fluids from the pump as described in the previous section.
2. Refill the pump with clean vacuum fluid as described in the section for changing the pump fluid.
3. Always cover both the intake and exhaust ports with caps to keep any dust or foreign materials from entering the pump. Place pump in original container if available.
4. Be sure that the pump is stored in a horizontal position with the intake and exhaust ports facing up.
5. When putting a pump into storage, put a pin hole in both the intake and exhaust port caps.

## 6.4 AVOIDING OIL LEAKS DURING SHIPPING AND STORAGE

Always drain your vacuum pump of all fluids before shipping. Failure to do so can result in damaged shipping containers and delays by freight carriers due to possibility of the presence of hazardous materials in the event of a spill.

## 7. TROUBLE-SHOOTING

SYMPTOM	CAUSE	SOLUTION
Motor will not turn or pump is seized	No Power	Supply power
	Power switch or starter defective	Change the power switch or starter
	Protector or protector circuit opened	Change the protector or fix the protecting circuit
Humming motor, will not turn	One power cord opened	Check the power cord
	Power switch or starter defective	Change the power switch or starter
	Motor winding open	Change the motor winding
	Bearing defective	Change bearing
	Capacitor single phase defective	Change capacitor
	Working temperature below 15° C	Raise working temperature to 15° C or change lubricant
	Wrong lubricant	Change lubricant
Weak vacuum	Pump too small	Change to larger pump
	Wrong power frequency	Adjust power frequency
	Vacuum leakage	Check system and process for leaks
	Oil contaminated	Change oil
	Exhaust filter blocked	Change or clean filter
	Air filter blocked	Change air filter
	Vane defective	Change vane
	Vacuum meter defective	Change vacuum meter
Weak pumping speed.	Exhaust filter clogged	Clean or change exhaust filter
	Air filter blocked	Change air filter

SYMPTOM	CAUSE	SOLUTION
Overheating	Working temperature exceed 40° C	Reduce working temperature
	Cooling air deficient	Change installation place or improve air flow
	Dirt in housing of motor or cylinder	Clean out dirt
	Less oil	Add oil
	Sucking air temperature too high	Reduce temperature of sucking air
White mist from exhaust cover	Exhaust filter blocked or damaged	Change exhaust filter
	Too much oil	Leak oil
Emulsify oil	Moisture	Change oil or open gas ballast valve

## 8. SPARE PARTS

NO.	DESCRIPTION	PART NUMBER
1	Cylinder	2CPCYA001
2	A-end plate	2CPEPA021
3	Bearing	313BR3010
4	Shaft seal	316SL3070
5	O-Ring	316SL3080
6	Elbow stud fitting	337PUM040
7	Hex. Head screw	
8	Spring lock washer	
9	Rotor	313PLE020
10	Sleeve	313BR1030
11	Vane	2CPPU3010
12	B-end plate	2CPEPB021
13	Elbow stud fitting	337PUM020
14	Tapper pin	337PUM010
15	Shaft key	338KY2150
16	Coupling Rubber	316RB4080
17	Separator gasket	333PK1030
18	Oil separator	2CPOSA0A1
19	Drum plug	331SN1070
20	Plug	332PU1110
21	Oil sight glass	312PUM130
22	O-Ring	316SL3210
23	Demister	2CPRV4001
24	Hollow core screw	331SH1320

NO.	DESCRIPTION	PART NUMBER
25	Exhaust filter	31ZPU2010
26	Spring	33BPUM010
27	Seal	33ZPU1010
28	Exhaust cover	315PUM010
29	Screw	
30	Rubber gasket	316RB1060
31	O-Ring	316SL3210
32	Spring screw	331SH1190
33	Rubber foot	33ZRU1020
34	Inlet flange	2CPIFA001
35	Inlet screw	33ZPU1030
36	Retaining ring	335EP1100
37	Valve plate	315PUM030
38	Compression spring	33BPUM020
39	Guide	315PUM020
40	Lock screw	
41	Spring washer	
42	Cooling Spiral Tube	32ZPU1010
43	Oil tube	31ZPU1020
47	Inlet oil plug	
74	Coupling set screw	2CPCUP012
76	Hex. lock screw	
77	Hex. Lock screw	
78	Plain washer	
79	Nut	
82	Plain washer	
83	Straight stud fitting	
84	Oil fill plug	
85	O-Ring	